



ITPC-B170

17" Fanless Industrial Touch Panel PC

Technical Support Documentation

Document Version:	1.0
Date:	February 2026
Product:	ITPC-B170
Platform:	Intel® Core™/Celeron® Processor
Classification:	Touch Panel PC

IWILL Technology | WhatsApp: +852 914 61951

United Kingdom
www.iwilltech.co.uk
support@iwilltech.co.uk

Poland
www.iwill.pl
wsparcie@iwill.pl

MENA Region
www.iwillmena.com
support@iwillmena.com

Denmark
www.iwill.dk
stotte@iwill.dk

Portugal & Spain
www.iwill.pt
apoyo@iwill.pt

Bulgaria
www.iwill.bg
support@iwill.bg

All product specifications are subject to change without notice.

Table of Contents

- 1. Product Overview**
- 2. Hardware Specifications**
- 3. I/O Interfaces & Connectivity**
- 4. Mechanical Dimensions**
- 5. BIOS Configuration**
- 6. Operating System Installation**
- 7. Touchscreen Configuration**
- 8. Expansion Module Installation**
- 9. Mounting Guide**
- 10. Maintenance & Troubleshooting**
- 11. Warranty & Support**
 - Appendix A — Order Information & Accessories

1. Product Overview

The ITPC-B170 is a 17" fanless industrial touch panel PC designed for demanding environments requiring reliable, maintenance-free operation. Built with an aluminum alloy chassis and IP65-rated front panel, it combines computing performance with industrial-grade durability.

1.1 Key Features

- Fanless Aluminum Design
- Intel® Core™/Celeron® Processor
- COM2 Support RS232/485
- (4 x COM Ports optional)
- IP65 full flat front panel
- Support VESA Mount, Wall Mount ect.

1.2 Target Applications

The ITPC-B170 is suitable for Industrial Automation, Medical, Logistics Transportation, Warehousing, Electronic Education, etc..

1.3 Package Contents

Verify the following items are included in the package:

Item	Qty	Description
Power Adapter	1	12V 5A
Power Cord	1	CN, US, UK, EU etc.
Embedded Buckle	4	For Standard Embedded Installation
Desktop, Wall Mount, Stereo Stand	1	Optional

NOTE: If any item is missing or damaged, contact IWILL Technology support immediately at support@iwilltech.co.uk.

2. Hardware Specifications

Complete technical specifications for the ITPC-B170.

SYSTEM	
Model	ITPC-B170
Processor	Intel® Core™/Celeron® Processor
Memory	1 x DDR3 1333/1600MHz SODIMM, Max. 8GB (Intel® Core™ i5-4200U)
BIOS	AMI UEFI BIOS
Graphics	Intel® HD Graphics 4400 (Intel® Core™ i5-4200U)
Display Ports	1 x HDMI, 1 x LVDS, 1 x VGA Support synchronous/asynchronous 2 display 1 x MSATA
Storage	1 x 2.5-inch HDD/SSD
Expansion	1 x Mini PCIe (support WiFi/4G optional)
OS Support	Windows 7, Windows 8, Windows 10, Linux
I/O PORTS	
Ports	2 x USB 2.0 2 x RTL8111H 1000Mbps LAN Ports 1 x Mic 1 x Line Out 2 x COM Ports (COM2 RS232/RS485 optional)
POWER & OTHER	
Power Input	DC 12V
DISPLAY & TOUCH	
Display Type	17" TFT-LCD
Brightness	300 cd/m ²
Viewing Angle	80/80/80/80
Contrast	4:3
Resolution	1280 x 1024
Touch Type	Multi-touch Capacitive touch screen, Lifetime: more than 50000 Thousand Times
ENVIRONMENT	
Operating Temp.	0■ ~ 50■, surface air flow
Humidity	5% ~ 95% (non-condensing)
Certifications	CE, CCC, FCC Class A, RoHS
MECHANICAL	
Dimensions	380 x 315 x 45 mm
Weight	3.77 kg

3. I/O Interfaces & Connectivity

3.1 I/O

Connector	Description
2	2 × USB 2.0
2	2 × RTL8111H 1000Mbps LAN Ports
1	1 × Mic
1	1 × Line Out
2	2 × COM Ports (COM2 RS232/RS485 optional)

WARNING: Always power off the unit and disconnect all power sources before connecting or disconnecting any internal components.

4. Mechanical Dimensions

All dimensions are in millimeters (mm).

Parameter	Value
Overall Dimensions	380 x 315 x 45 mm
Weight	3.77 kg

NOTE: For detailed technical drawings with mounting hole positions, contact IWILL Technology at support@iwilltech.co.uk.

5. BIOS Configuration

The ITPC-B170 uses AMI UEFI BIOS. Access the BIOS setup by pressing **DEL** or **F2** during the POST screen at boot.

5.1 Entering BIOS Setup

1. Connect a USB keyboard to the unit.
2. Power on the system.
3. Press **DEL** or **F2** repeatedly as the splash screen appears.
4. The AMI UEFI BIOS setup utility will load.

5.2 Important BIOS Settings

Setting	Location	Description
Boot Order	Boot Tab	Set primary boot device (SSD, USB, PXE)
Power On After Power Loss	Advanced > ACPI	Set to [Power On] for automatic startup on power restoration
Wake-on-LAN	Advanced > Network	Enable for remote wake capability over LAN

NOTE: BIOS menu paths may vary between firmware revisions. If a setting is not found, check adjacent menus or consult IWILL Technology support.

5.3 BIOS Reset

Method 1 (Keyboard): Enter BIOS setup and press **F9** to load optimized defaults, then **F10** to save and exit.

Method 2 (CMOS Reset): Power off, disconnect power, open the chassis, locate the CMOS clear jumper on the motherboard, short for 5 seconds, then remove.

6. Operating System Installation

6.1 Supported Operating Systems

OS	Notes
Windows 7	64-bit, legacy support
Windows 8/8.1	64-bit
Windows 10	64-bit (21H2+). Recommended for most deployments.
Linux	Ubuntu 22.04+, CentOS, or compatible distributions.

6.2 Installation via USB

1. Prepare a bootable USB drive with the desired OS image (use Rufus, balenaEtcher, or dd).
2. Insert the USB drive into an available USB port.
3. Enter BIOS (DEL/F2) and set USB as the first boot device.
4. Save and restart. The OS installer should load from USB.
5. Follow on-screen instructions. Select the internal drive as the install target.
6. After installation, re-enter BIOS and restore the internal drive as primary boot device.

6.3 Driver Installation

Windows 10/11 should automatically detect most hardware via Windows Update. For chipset, graphics, and LAN drivers, download the latest versions from Intel's support site or contact IWILL Technology for the driver package.

7. Touchscreen Configuration

7.1 Windows Touch Calibration

The industrial touchscreen is pre-calibrated at the factory. If recalibration is needed:

1. Open **Control Panel > Tablet PC Settings**.
2. Click **Calibrate...** under the Display tab.
3. Select **Touch input** and follow the on-screen crosshair targets.
4. Tap **Save** to store the calibration data.

7.2 Linux Touch Configuration

On Linux, the touchscreen is typically managed by the **hid-multitouch** kernel module. Use **xinput** to list and configure touch devices.

7.3 Multi-Touch Support

The capacitive touchscreen supports multi-touch gestures (pinch-to-zoom, two-finger scroll) natively in Windows 10/11 and in Linux with libinput.

8. Expansion Module Installation

8.1 Available Expansion Slots

- 1 x Mini PCIe (support WiFi/4G optional)

8.2 Installation Procedure

1. Power off and disconnect all power sources.
2. Remove the chassis access panel screws.
3. Locate the target expansion slot on the motherboard.
4. Insert the module at a 30° angle and press down until it clicks into the retaining clip.
5. If applicable, connect antenna pigtail cables to the module's U.FL connectors.
6. Replace the access panel and secure with screws.

WARNING: Always use ESD protection (grounding strap) when handling internal expansion modules. Static discharge can permanently damage components.

8.3 Storage Installation

- 1 x 2.5-inch HDD/SSD

9. Mounting Guide

9.1 Panel Cutout Preparation

Insert the unit into the panel cutout from the front. From the rear, attach the mounting clamps and tighten evenly to compress the gasket seal against the panel surface.

9.2 VESA / Desktop Mounting

The ITPC-B170 supports VESA mounting (check rear panel for mounting hole pattern). Use M3 or M4 screws as appropriate — do not exceed the maximum thread depth.

WARNING: Ensure adequate ventilation around the unit. Do not block the heatsink fins or ventilation openings.

10. Maintenance & Troubleshooting

10.1 Routine Maintenance

- **Screen Cleaning:** Use a soft, lint-free cloth with isopropyl alcohol. Do not use abrasive cleaners.
- **Heatsink Cleaning:** Periodically blow out dust from the heatsink fins using compressed air.
- **Connector Inspection:** Check connectors for damage or corrosion, especially in harsh environments.
- **Firmware Updates:** Check with IWILL Technology for BIOS updates that may improve stability.

10.2 Troubleshooting Guide

Symptom	Possible Cause	Solution
No power / no LED	Power adapter disconnected or faulty	Verify DC input voltage. Try a different adapter.
No display output	Display cable loose or BIOS setting	Reseat display cable. Check BIOS display settings.
Touch not responding	Driver missing or USB disconnected	Install touch driver. Check internal USB connection.
System freezes	Memory or storage issue	Reseat RAM. Test with known-good SSD. Enable watchdog.
Overheating	Blocked heatsink or high ambient temp	Clean heatsink. Ensure adequate airflow.
Boot loop	Corrupted BIOS or OS	Reset BIOS to defaults (F9). Reinstall OS.

11. Warranty & Support

11.1 Warranty Coverage

The ITPC-B170 is covered by a standard manufacturer warranty. The warranty covers defects in materials and workmanship under normal use conditions. It does not cover damage from misuse, unauthorized modifications, or exposure beyond rated specifications.

11.2 Technical Support

IWILL Technology provides worldwide technical support through regional offices:

Region	Website	Email
United Kingdom	www.iwilltech.co.uk	support@iwilltech.co.uk
MENA Region	www.iwillmena.com	support@iwillmena.com
Portugal & Spain	www.iwill.pt	apoyo@iwill.pt
Poland	www.iwill.pl	wsparcie@iwill.pl
Denmark	www.iwill.dk	stotte@iwill.dk
Bulgaria	www.iwill.bg	support@iwill.bg

WhatsApp: +852 914 61951

11.3 RMA Process

To initiate a return for repair or replacement, contact IWILL Technology support at the regional office nearest to your location with your product serial number and a description of the issue.

Appendix A — Order Information & Accessories

A.1 Order Configurations

Configuration	Description
ITPC-B170 CPU Specification	ITPC-B170 CPU Specification
Configuration 1 Intel® Celeron® J1900 St	Configuration 1 Intel® Celeron® J1900 Standard I/O (1 x USB 3.0, 3 x USB 2.0)
Configuration 2 Intel® Core™ i5-4200U St	Configuration 2 Intel® Core™ i5-4200U Standard I/O
Configuration 3 Intel® Core™ i5-6360U St	Configuration 3 Intel® Core™ i5-6360U Standard I/O (2 x Intel I211 LAN Ports)

A.2 Included Accessories

Item	Qty	Specification
Power Adapter	1	12V 5A
Power Cord	1	CN, US, UK, EU etc.
Embedded Buckle	4	For Standard Embedded Installation
Desktop, Wall Mount, Stereo Stand	1	Optional

IWILL Technology | WhatsApp: +852 914 61951

United Kingdom
www.iwilltech.co.uk
support@iwilltech.co.uk

Poland
www.iwill.pl
wsparcie@iwill.pl

MENA Region
www.iwillmena.com
support@iwillmena.com

Denmark
www.iwill.dk
stotte@iwill.dk

Portugal & Spain
www.iwill.pt
apoyo@iwill.pt

Bulgaria
www.iwill.bg
support@iwill.bg

All product specifications are subject to change without notice.